

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 19436**

2007 Chevrolet Tahoe / GMC Yukon 5.3L



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. inlet pipe/muffler/tail pipe/resonator assembly from vehicle. Lubricate the rubber isolator with WD-40, or a similar product, to aid in removal of the metal rod hangers.

2. Install DynoMax exhaust pipe **52300**. Insert the metal rod hanger into the rubber isolator on the chassis. Finger tighten the nuts on the inlet flange.

3. Install DynoMax Ultra Flo Welded muffler **17235**. The muffler should lie flat and install with the center connection as the inlet and with the side outlet connection toward the passenger side. Finger tighten the 3" inlet clamp at the connection to the front pipe.

4. Install DynoMax tail pipe **55322**. Insert the three (3) metal rod hangers into the rubber isolators on the chassis. Finger tighten the 3" clamp to the muffler outlet.

5. Beginning at the inlet end, align the exhaust system components and fully tighten all the clamps
6. Please see system diagram on back page of these instructions.

KIT CONTAINS:

- (1) 17235 MUFFLER
- (1) 52300 INLET PIPE
- (1) 55322 TAIL PIPE
- (2) 3" BAND CLAMPS
- (1) 703058 INSTRUCTION SHEET

19436 SYSTEM DIAGRAM

