

**INSTALLATION INSTRUCTIONS FOR  
DYNOMAX KIT: 19465**  
1981-78 Chevrolet Corvette (350 C.I.D.)



2701 N. Dettman Rd.  
Jackson, MI 49201

**DANGER WARNING:** SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

**NOTE: Read all instructions before starting any work.**

1. Remove the old exhaust system. Lubricate the old clamps with WD-40, or similar product, to aid in removal.
2. Install DynoMax front y-pipe **50446**. Finger tighten the inlet fasteners to hold the pipe in place.
3. Install DynoMax Super Turbo mufflers **17757 RH and LH**. The muffler inlet pipe and outlet spout are included in the muffler carton along with (2) 2 1/2" clamps. Finger tighten the 2 1/2" inlet and outlet clamps.

KIT CONTAINS:

- (2) 17757 MUFFLERS  
(Each muffler includes inlet pipe, spout and 2 Clamps)
- (1) 50446 Y-PIPE
- (2) 2 1/2" U-BOLT CLAMPS
- (1) 705591 INSTRUCTION SHEET

4. Beginning at the inlet end, align the system components and fully tighten all the clamps.
5. Please see the system diagram on the back page of these instructions.

# 19465 SYSTEM DIAGRAM

