

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 39311**

2007-99 Chevrolet Silverado / GMC Sierra, 1500/2500
(<8600 G.V.W.R.) 4.3L, 4.8L, 5.3L Ext. Cab, Short Bed
(143.5" W.B., 2007 Classic Models ONLY)



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. muffler assembly Lubricate the rubber insulators with WD-40, or a similar product, to aid in removing the rod brackets.
2. Install DynoMax intermediate pipe **55512**. Insert the rod hanger into the rubber isolator hanger.
3. Install DynoMax Ultra Flow Welded muffler **17223**.

4. Install tail pipe **55513**. Insert the rod hanger into the rubber isolator hanger.
5. Beginning at the inlet end, position all components and tighten all clamps.
6. Start engine and check for leaks or rattles. Adjust as required.
PLEASE SEE THE FULL SYSTEM DIAGRAM ON THE BACK PAGE.

KIT CONTAINS:

- (1) 17223 MUFFLER
- (1) 55512 PIPE
- (1) 55513 PIPE
- (2) 3" CLAMPS
- (1) 709088 INSTRUCTION SHEET

39311 SYSTEM DIAGRAM

