

**INSTALLATION INSTRUCTIONS FOR
DYNOMAX KIT: 39459**

2009-07 Jeep Wrangle (JK) Unlimited (4 Door) 3.8L
w/ Rock Crawler Type-Off-Road Suspension System



2701 N. Dettman Rd.
Jackson, MI 49201

DANGER WARNING: SHOULD THE PURCHASER DECIDE TO INSTALL ANY EXHAUST PRODUCT AT HOME, BE WARNED THAT PASSENGER CAR OR LIGHT DUTY TRUCK/VAN "BUMPER" JACKS ARE INTENDED FOR EMERGENCY USE ONLY. THE USE OF FRAME CONTACT JACK STANDS IN CONJUNCTION WITH A FLOOR JACK AS MAIN SUPPORT IS HIGHLY RECOMMENDED TO MINIMIZE ACCIDENTAL DROPPING OF A VEHICLE DURING THE INSTALLATION PROCESS.

NOTE: Read all instructions before starting any work.

1. Remove the O.E. exhaust from behind the catalytic converters. Lubricate the rubber isolators with WD-40, or a similar product, to aid in removal of the metal rod hangers.
2. Install DynoMax front intermediate pipe **52355**. Insert the rod hangers into the rubber isolator. Slightly tighten the 2½" clamp on the inlet end.
3. Install muffler **17263**. Slightly tighten the 2½" clamp that connects this muffler to the outlet of the 52355 front pipe.

4. Install tail pipe **56157**. Be sure to insert the metal rod hangers into the rubber isolators. Slightly tighten the 2½" clamp that connects the tail pipe to the muffler outlet.
5. Install the DynoMax tip **36443** on the outlet of the tail pipe.
6. Beginning at the inlet end, align the system components and fully tighten all the clamps. Please see the system diagram on the back page of these instructions.

KIT CONTAINS:

- (1) 17263 MUFFLER
- (1) 52355 FRONT PIPE
- (1) 56157 TAIL PIPE
- (1) 36443 TIP
- (4) 2½" BAND CLAMPS
- (1) 709040 INSTRUCTION SHEET

39459 SYSTEM DIAGRAM

